# **INSTRUCTION &** xpres INFORMATION

### **UNIVERSAL APPLICATION TAPE**

Cut a piece of application tape slightly

bigger than your design, peel the backing and carefully lay on top of the

Using a squeegee with pressure, flatten the application tape down and

Flip over the transfer and application

sheet (now stuck together), and peel the backing off the printable media. Now only the weeded design should remain on the application tape.

Position the design onto the garment sticky side down (the sticky backing will aid the placement). Cover with a silicone sheet and press using the

smooth out any bubbles.

recommended settings.

#### XP3139 50cm wide x 25m . XP3140 75cm wide x 25m

Universal Application Tape has been specially developed to work with all solvent & latex printable media from Xpres. 50cm & 75cm samples are available free of charge upon request.

#### **STEP BY STEP**

**STEP 1** 

**STEP 2** 

transfer. **STEP 3** 

**STEP 4** 

**STEP 5** 

## **COMPATIBILITY CHART**

**EVOLUTION PRINT** 

SUPERFLEX PRINT

**EASY PRINT** 

SOLVENT DARK PLUS

SUBLI BLOCK SOFT TURBO

**SUBLI BLOCK** 

**NYLO PRINT** 

NYLO PRINT MATT

**COLOUR CUT** 

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of Universal Application Tape be liable for any injury direct or consequential, arising out of the use of, or inability to use this range. .



Web: www.xpres.co.uk Support www.xprestechnical.co.uk Oakridge Park, Trent Lane, Castle Donington, Derby DE74 2PY Phone: 01332 855 085 E-mail: sales@xpres.co.uk

Print and cut design on the printable material. Once cut, weed away the excess material around the design.