xpres INSTRUCTION & INFORMATION

SUBLI TEX®

XP3144 - A4 sheets $\,\cdot\,$ XP3143 - A3 sheets

A twill textured transfer paper printed using a sublimation printer for heat transfer application onto cotton, polyester and polycotton textiles.

A4 samples are available free of charge upon request. Xpres cannot be held responsible for any copier/printer breakages.

STEP BY STEP

STEP 1

Print your design on the textured side of Subli Tex along with the Xpres Cut Plus registration marks. (Templates can be found at www.xprestechnical.co.uk) - **Do Not Mirror Image**

STEP 2

Contour cut using the Xpres Cut Plus process - (The manual for this process is available to download from www. xprestechnical.co.uk) Flock blade required (100-120gf).

STEP 3

Weed away any excess material, remove the transfer and position on the garment by hand.

STEP 4

Cover the transfer with two silicone sheets and press for 50 seconds at 170°C.

STEP 5

Remove the silicone sheet when hot.

ACCREDITATIONS



PRINT SETTINGS

Please visit www.xprestechnical.co.uk for the relevant printer profile.

SUITABLE FOR

COTTON

POLYESTER

POLYESTER/COTTON (uncoated garment only)

| TRANSFER SETTINGS | |
|-------------------|------------|
| ТІМЕ | 50 seconds |
| ТЕМР | 170°C |
| PRESSURE | Medium |
| PEEL | Hot |

CARE INFORMATION

WASH UP TO 60°C INSIDE OUT

CAN BE TUMBLE DRIED

DO NOT DRY CLEAN

CAN BE IRONED INSIDE OUT

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of Subli Tex shall be liable for any injury direct or consequential, arising out of the use of, or inability to use this range. Subli Tex has been tested using Kustom Kit garments, use on other garment brands can not be guaranteed and should be tested prior to purchasing this material.



 Web: www.xpres.co.uk
 Support www.xprestechnical.co.uk

 Oakridge Park, Trent Lane, Castle Donington, Derby DE74 2PY
 Phone: 01332 855 085
 E-mail: sales@xpres.co.uk